

C:\Users\Dani\AppData\Local\Programs\Python\Python37-32\Lib\site-packages

```
esptool.py --chip esp32 --port COM7 --baud 460800 --before default_reset --after no_reset  
write_flash -z --flash_mode dio --flash_freq 40m --flash_size detect 0x1000  
bootloader/bootloader.bin 0xf000 phy_init_data.bin 0x10000 MicroPython.bin 0x8000  
partitions_mpy.bin
```